



ata **MANUAL**

OVERHAUL

ELECTRO-PNEUMATIC CONTINUOUS FLOW CONTROL UNIT

P/N 22504-7

P/N 22504-9

P/N 22504-11

P/N 22504-13

35-20-118B

H-118B

Jun 29/87

SCOTT®

SCOTT AVIATION • A FIGGIE INTERNATIONAL COMPANY
Lancaster, New York 14086
PRINTED IN U.S.A.



22504
OVERHAUL MANUAL

LIST OF EFFECTIVE PAGES

Insert latest revised pages, destroy superseded pages.

Page	Date	Page	Date
*Title	Jun 29/87	516	Apr 15/84
Service Bulletin	Apr 15/84	*517	Jun 29/87
List		*518	Jun 29/87
*List of Effective	Jun 29/87	*519	Jun 29/87
Pages		*520	Jun 29/87
*Record of Revisions	Jun 29/87	*521	Jun 29/87
Record of Temporary	Apr 15/84	*522	Jun 29/87
Revisions		*523	Jun 29/87
Table of Contents	Apr 15/84	*524	Jun 29/87
i	Apr 15/84	601	Apr 15/84
ii (Blank)	Apr 15/84	602 (Blank)	July 15/72
*1	Jun 29/87	*701	Jun 29/87
*2	Jun 29/87	*702	Jun 29/87
*3	Jun 29/87	703	Apr 15/84
*4	Jun 29/87	704	Apr 15/84
5	Apr 15/84	*705	Jun 29/87
6	Apr 15/84	*706	Jun 29/87
*101	Jun 29/87	*707	Jun 29/87
*102	Jun 29/87	708 (Blank)	July 15/72
103	Apr 15/84	*801	Jun 29/87
104	Apr 15/84	*802	Jun 29/87
201	Apr 15/84	803	Apr 15/84
202 (Blank)	July 15/72	804 (Blank)	July 15/72
301	Apr 15/84	901	Apr 15/84
302 (Blank)	July 15/72	902 (Blank)	July 15/72
401	Apr 15/84	1001	Apr 15/84
402	Apr 15/84	1002	Apr 15/84
501	Apr 15/84	*1101	Jun 29/87
502	Apr 15/84	*1102	Jun 29/87
*503	Jun 29/87	*1103	Jun 29/87
*504	Jun 29/87	*1104	Jun 29/87
*505	Jun 29/87	*1105	Jun 29/87
*506	Jun 29/87	*1106	Jun 29/87
507	Apr 15/84	*1107	Jun 29/87
508	Apr 15/84	*1108	Jun 29/87
*509	Jun 29/87	*1109	Jun 29/87
*510	Jun 29/87	*1110	Jun 29/87
511	Apr 15/84	*1111	Jun 29/87
512	Apr 15/84	*1112	Jun 29/87
*513	Jun 29/87	*1113	Jun 29/87
*514	Jun 29/87	*1114	Jun 29/87
515	Apr 15/84		

*The asterisk indicates pages revised or added by the current revision.

SCOTT
22504
OVERHAUL MANUAL

RECORD OF REVISIONS

REV NO.	ISSUE DATE	DATE INSERTED	BY	REV NO.	ISSUE DATE	DATE INSERTED	BY
1	Mar 1/66						
2	Mar 15/67						
3	July 15/72						
4	Apr 15/76						
5	Apr 15/84						
6	Jun 29/87						

35-20-118B
Record of Revisions
Jun 29/87

SCOTT
22504-7, -9, -11
OVERHAUL MANUAL

RECORD OF TEMPORARY REVISIONS

TEMPORARY REV. NO.	PAGE NUMBER	ISSUE DATE	BY	DATE REMOVED	BY

35-20-118B
Record of Temporary Revisions
Apr 15/84



22504-7, -9, -11
OVERHAUL MANUAL

TABLE OF CONTENTS

Paragraph		Page No.
	Important Warnings	i
1	Description and Operation	1
2	Disassembly	101
3	Cleaning	201
4	Inspection/Check	301
5	Repair	401
6	Assembly	501
7	Fits and Clearances	601
8	Testing	701
9	Trouble Shooting	801
10	Storage Instructions	901
11	Special Tools, Fixtures and Test Equipment	1001
12	Illustrated Parts List	1101

35-20-118B

Table of Contents
Apr 15/84

SCOTT

22504-7, -9, -11
OVERHAUL MANUAL

IMPORTANT WARNINGS

WARNING: ANY SERVICE OR OVERHAUL PERFORMED ON THIS APPARATUS SHALL BE DONE ONLY BY THOSE FACILITIES EXPERIENCED IN, OR BY PERSONNEL KNOWLEDGEABLE IN HIGH PRESSURE AVIATION OXYGEN EQUIPMENT. IF NONE ARE KNOWN, CONTACT SCOTT AVIATION OR ITS DISTRIBUTORS FOR NAMES OF AUTHORIZED SERVICE CENTERS.

WARNING: ALL PROCEDURES DESCRIBED IN THIS MANUAL SHALL BE PERFORMED IN AN AREA FREE OF OIL, GREASE, FLAMMABLE SOLVENTS OR OTHER COMBUSTIBLE MATERIALS. SUCH MATERIALS, AS WELL AS DUST, LINT, AND FINE METAL FILINGS ARE ALL POTENTIAL COMBUSTIBLES WHICH MIGHT, WHEN EXPOSED TO OXYGEN UNDER PRESSURE IGNITE AND RESULT IN AN EXPLOSION AND/OR FIRE.

WARNING: DO NOT ALLOW OIL, GREASE, FLAMMABLE SOLVENTS, OR OTHER COMBUSTIBLE MATERIALS TO COME IN CONTACT WITH PARTS THAT WILL BE EXPOSED TO PRESSURIZED OXYGEN. SUCH MATERIALS, AS WELL AS DUST, LINT, AND FINE METAL FILINGS ARE ALL POTENTIAL COMBUSTIBLES WHICH MIGHT, WHEN EXPOSED TO OXYGEN UNDER PRESSURE, IGNITE AND RESULT IN AN EXPLOSION.

35-20-118B


Page i/ii
Apr 15/84

ELECTRO-PNEUMATIC CONTINUOUS FLOW CONTROL UNIT1. Description and OperationA. General

- (1) This manual provides overhaul instructions with illustrated parts list for Electro-Pneumatic Continuous Flow Control Units, part number 22504-7, 22504-9, 22504-11 and 22504-13 (see figure 1).

B. Purpose of Equipment

- (1) The Electro-Pneumatic Continuous Flow Control Unit, hereafter referred to as the control unit, forms part of the aircraft emergency oxygen system when installed in a pressurized cabin. When the cabin pressure drops below a pressure equivalent to 13,250 to 14,500 feet altitude for 22504-7, 22504-9 and 22504-13 and to 14,000 to 15,000 feet altitude for 22504-11, the control unit automatically initiates and controls the flow of oxygen from a high pressure gaseous oxygen source to the passenger mask compartments. The control unit may also be activated electrically at any altitude.




Electro-Pneumatic Continuous
Flow Control Unit
Figure 1

C. Typical Installation

- (1) A typical pressurized cabin installation is shown in figure 2. An oxygen source consisting of a series of high pressure oxygen storage cylinders (1) is connected to the inlet of Pneumatic Continuous Flow Control Unit (2) and Electro-Pneumatic Continuous Flow Control Unit (3) to the passenger mask compartments (4).

NOTE: Refer to Overhaul Manual, 35-20-118A, for complete overhaul instructions for Pneumatic Continuous Flow Control Unit (2).

- (2) Control units (2 and 3) are normally closed. In the event of cabin decompression (cabin pressure drops below 13,250 to 14,500 feet for 22504-7, 22504-9 and 22504-13 or 14,000 to 15,000 feet for 22504-11), the aneroids within control units (2 and 3) are preset to automatically open and control the flow of oxygen to passenger mask compartments (4). If required, the system may be activated manually at control unit (2) and/or electrically by a crew member from the cockpit of the aircraft through control unit (3), to supply oxygen to passenger mask compartment (4). (Switch (5) controls electrical actuation of control unit (3).)



Typical Installation
Figure 2

22504
OVERHAUL MANUAL


- (3) Inlet pressure is monitored continuously on gauge (6) in the cockpit of the aircraft through a pressure transducer in control unit (3). When the system is activated either automatically, manually, or electrically, light (7) in the cockpit of the aircraft and in the passenger compartment is illuminated indicating presence of outlet pressure. This outlet pressure indication is possible through a pressure switch in control unit (3).

NOTE: The 22504-9 and 22504-13 control units (3) do not contain a pressure transducer (see IPL figure 1).

D. Operation (See figure 3)

- (1) Pressure Reducer. When oxygen at pressures ranging from full cylinder pressure (1850 psi) down to 300 psi is introduced at the inlet of the control unit, the miniaturized single stage pressure reducer reduces the pressure to a relatively constant value of approximately 100 psig. This controlled first stage pressure is routed to the pilot-operated main flow control valve and to the actuation valve.
- (2) Automatic Actuation. At an altitude of 13,250 to 14,500 feet for 22504-7, 22504-9 and 22504-13 or 14,000 to 15,000 feet for 22504-11, the aneroid in the automatic actuation mechanism develops sufficient force to overcome the tension of the leaf spring. The force trips the leaf spring past center and moves the lever against the actuation valve, which then opens and allows the first stage pressure to be applied to the pilot flow controlling orifice and to the surge valve.
- (3) Electrical Actuation. The system may be actuated electrically at any altitude by momentarily energizing the solenoid switch in the cockpit of the aircraft. Actuation of the solenoid within the electro-pneumatic control unit overrides a detent causing positive opening of the actuation valve, overriding (by-passing) the automatic mechanism. The locking detent holds the unit in the "ON" mode until manually reset.
- (4) Manual Reset. (Cabin pressure must be below 12,000 feet altitude). After actuation (automatic or electrical) the control unit may be reset by depressing the manual reset mechanism. The automatic actuation and electrical actuation capabilities are retained after resetting.

50011
22504
OVERHAUL MANUAL



System Schematic
Figure 3

NOTE **⚠**

THE 22504-9 AND 22504-13 SERIES CONTROL UNITS DO NOT CONTAIN A PRESSURE TRANSDUCER

35-20-118B

Page 4
Jun 29/87

- (5) **Pressure Surge.** When the actuation valve opens, first stage pressure is admitted underneath the surge valve diaphragm. The pressure in the closed volume above the surge valve diaphragm is initially at ambient. At actuation, the sudden large pressure differential opens the surge valve and admits oxygen into the pilot volume above the main flow control valve diaphragm. With the surge valve open, the pressure in the pilot volume is then nearly equal to the first stage pressure. This occurs because the restriction of flow from the pressure reducer to the pilot volume is small compared to the restriction from the pilot volume to the unit outlet via the pilot valve.

This pilot surge pressure acting on the main flow control valve diaphragm opens the main valve fully and allows oxygen to flow into the outlet. This flow is sufficiently large to pressurize the aircraft system (approximately 670 cu. in.) to a pressure of 50 psig in 4 seconds. The outlet pressure builds up to a value slightly less than the first stage pressure.

The pressure in the closed volume above the surge valve diaphragm gradually rises as oxygen flows through the equalizing orifice located in the surge valve diaphragm assembly. After a period of 7 to 15 seconds, when the pressure differential across the surge valve diaphragm is reduced to approximately 10 to 15 psi, a spring closes the surge valve. Now there is a definite restriction to flow from the pressure reducer to the pilot volume. The pilot pressure becomes equal to the outlet pressure and the bias spring closes the main flow control valve.

- (6) **Pilot Flow.** During normal operation, the pilot oxygen (approximately 1.3 SLPM) flows from the first stage through the actuation valve, through the pilot flow controlling orifice, through the pilot volume, through the pilot valve and into the outlet. The magnitude of the pilot pressure depends on the relative restriction upstream and downstream of the pilot volume. The upstream restriction consists of the pilot flow controlling orifice and is fixed. The downstream restriction consists of the pilot valve, and is variable.
- (7) **Pilot Operation.** The altitude-compensating aneroid exerts a force, tending to close the pilot valve, which is counteracted by the force of the outlet pressure acting on the feedback capsular element, tending to open the pilot

valve. The pilot valve moves in the direction of the unbalanced force. If the unit outlet pressure is higher than is demanded by the feedback element, the pilot valve opening increases, thereby decreasing the pilot pressure which in turn decreases the opening of the main flow control valve and reduces the output flow. If the feedback element demands a higher outlet pressure than is present in the outlet, the pilot valve opening decreases, increasing the restriction to flow, which raises the pilot pressure and increases the output flow.

- (8) Altitude Compensation. From ground level to approximately 17,000 feet, the altitude compensating aneroid does not contact the force transmitting lever arm and has no effect on the unit performance.

The feedback capsular element is pre-loaded so that a constant outlet pressure of approximately 4 psig is required to keep the pilot valve open. At approximately 17,000 feet the aneroid contacts the lever arm and develops a force, increasing linearly with decreasing ambient pressure, which adds to the pre-load force of the feedback element, and produces a corresponding increase in the outlet pressure.

- (9) Relief Valve (First Stage). The first stage pressure relief valve is integral with the inlet valve actuating shaft and seats on the pressure reducer diaphragm.

When the inlet valve is closed, a further buildup in the first stage pressure due to any leakage will first remove the force of the loading spring on the inlet valve. This is the force that balanced the force due to the inlet pressure. During this time there is no movement of the assembly. Then with a further pressure buildup the diaphragm assembly begins to move back against the loading spring carrying the relief valve with it.

When the relief valve contacts the rigid stop, the motion is arrested until the force of the first stage pressure against the relief valve is transferred from the diaphragm to the stop.

When the force of the pressure acting on the smaller annular diaphragm area equals the force of the loading spring, the diaphragm moves away from the relief valve and venting begins.

- (10) Relief Valve (OUTLET). A high flow capacity outlet pressure relief valve is incorporated to ensure that outlet pressure can never exceed 135 psi.

2. Disassembly (See IPL figure 1)

NOTE: Prior to disassembling a 22504 control unit, note the dash number and determine the parts applicable to that assembly (refer to "EFFECT CODE" column of the Illustrated Parts List). Disregard any instructions that do not apply to the particular assembly being overhauled.

- A. Remove mounting plate (27) by removing screws (28) and washers (29).
- B. Remove cover subassembly (19) and gasket (26) from housing assembly (163) by removing screws (3) and washers (4).
- C. Straighten and remove pin (6) to remove pin (5); then remove washers (7) and leaf (8).
- D. Remove identification plate (2 or 2A) from cover subassembly (19) only if replacement is required.
- E. Unthread and remove button (9); then remove washer (10), spring (11) and plunger (12). Remove packing (13) from plunger (12).
- F. Remove lens (14) by removing screws (15) and nuts (16); then remove plate (17) and gasket (18).
- G. Remove solenoid (20) and gasket (24) by removing screws (21) and washers (22). Remove connectors (23) and tubing (25) from leads of solenoid (20) only if the parts are to be replaced.
- H. Remove lever assembly (33 through 39) from housing assembly (163) by removing screws (30) and washers (31 and 32).
- I. Remove setscrew (33) and screw assembly (34).
- J. Remove lever assembly (35) from lever support (39) by removing nut (37) and washers (38) from pin (36). Remove spring (40).
- K. Unthread and remove aneroid assembly (41) and washer (42).
- L. Unthread and remove capsule assembly (43); then remove packing (45). Remove lock nut (44) from end of capsule assembly (43).
- M. Remove pin (46), stem (47), spring (48) and seat assembly (49) from housing assembly (163).
- N. Remove indicator assembly (53 through 59) from housing assembly (163) by removing screws (51) and washers (52).

- O. Remove indicator (53) from lever assembly (59) by removing screw (54) and washer (55).
- P. Remove washers (57 and 58) from lever assembly (59), then slide the lever assembly out of plate (56).
- Q. Remove tie bolt (60) from spring frame (66) by removing nuts (61). Remove leaf spring (62) from spring frame (66).
- R. Remove setscrew (64) and insert (65) from housing assembly (163). Then unthread aneroid assembly (63) from housing assembly (163).
- S. Remove spring frame (66) from housing assembly (163) by removing screws (67) and washers (68); then remove shim(s) (68A).
- T. Unthread detent assembly (50) from housing assembly (163).
- U. Unthread and remove housing (69); then disassemble valve assembly (71 through 75) as follows:

NOTE: Use wrench (10, figure 1002) to remove housing (69, IPL figure 1).
 - (1) Remove nuts (71 and 72) from stem (74).
 - (2) Spring (73) and seat (75) are free to be removed from stem (74).
- V. Remove packing (76) from seat (75).
- W. Remove screw assembly (80 and 81) from the housing assembly; then remove insert (80) from screw (81). Remove packing (82) from end of screw (81).
- X. Remove electrical leads from terminals of pressure switch (91). Remove washers (90 and 91A). Unthread the pressure switch from housing assembly (163); then remove packing (92) from end of pressure switch.
- Y. Remove electrical leads from terminals of pressure transducer (93). Remove the pressure transducer from housing assembly (163) by removing screws (94) and washers (95, 96, and 96A).
- Z. Remove screen (97), sleeve (98), packing (99) and ring (100) from inlet of pressure transducer (93).

- AA. Remove electrical cable assembly (85) from housing assembly (163) by removing screws (86) and washers (87).
- AB. Unthread and remove plug (83); then remove packing (84) from end of plug (83).
- AC. Unthread and remove relief valve (101); then remove packing (102) from end of relief valve (101).
- AD. Unthread and remove union (103); then remove packing (104) from end of union (103). Remove filters (105 and 106) from housing assembly (163).
- AE. Unthread and remove fitting (107); then remove packing (108) from end of fitting (107). Remove screen (109) from housing assembly (163).
- AF. Unthread and remove screw (110) from cap (111); then unthread and remove cap (111) after removing setscrew (112) and insert (113).

NOTE: Use wrench (4, figure 1002) to remove cap (111, IPL figure 1).

- AG. Remove spring (115) and rings (114 and 116); then unthread and remove retainer (117). Remove ring (118) and diaphragm assembly (119) from housing assembly (163).

NOTE: Use wrench (4, figure 1002) to remove retainer (117, IPL figure 1).

- AH. Remove poppet (120) from diaphragm assembly (119). Remove packing (121) from poppet (120).
- AI. Unthread and remove valve assembly (123 through 128) from housing assembly. Remove packing (129) from the valve assembly. Disassemble the valve assembly as follows:

- (1) Unthread head (123) from stem (125).
- (2) Remove spring (124), guide (128), washer (127) and seat (126) from stem (125).

AJ. Unthread and remove locknut (130) and cap (131). Remove disc (133) and spring (134); then remove packing (132) from end of cap (131).

NOTE: Use wrench (8, figure 1002) to remove lock nut (130, IPL figure 1) and wrench (7, figure 1002) to remove cap (131, IPL figure 1).

AK. Remove orifice and diaphragm assembly (136 through 143) and disassemble as follows:

- (1) Unthread and remove setscrew (136) from orifice assembly (143); then remove screens (137 and 139) and packing (138) from the orifice assembly.
- (2) Remove nut (140), ring (141) and diaphragm (142) from other end of orifice assembly (143).

AL. Remove body (144), washer (146) and diaphragm (147) from housing assembly (163); then remove packing (145) from end of body (144).

AM. Remove valve assembly (150 through 156) from housing assembly (163).

NOTE: Use wrench (9, figure 1002) to remove the valve assembly from the housing assembly.

AN. Remove packing (157, IPL figure 1) and ring (148) from the valve assembly; then disassemble the valve assembly as follows:

- (1) Unthread retainer (150) from valve stem (154). Remove guide (151) and spring (152) from end of stem (154).
- (2) Unthread nut (153) and remove stem (154) from seat assembly (156).
- (3) Remove guide (155) from seat assembly (156).

AO. Remove valve (158) from housing assembly (163).

AP. Remove instruction plate (159) and name plate (161) by removing screws (160 and 162) only if the plates are to be replaced.

3. Cleaning

WARNING: DO NOT ALLOW OIL, GREASE, FLAMMABLE SOLVENTS, OR OTHER COMBUSTIBLE MATERIALS TO COME IN CONTACT WITH PARTS THAT WILL BE EXPOSED TO PRESSURIZED OXYGEN. SUCH MATERIALS, AS WELL AS DUST, LINT, AND FINE METAL FILINGS ARE ALL POTENTIAL COMBUSTIBLES WHICH MIGHT, WHEN EXPOSED TO OXYGEN UNDER PRESSURE, IGNITE AND RESULT IN AN EXPLOSION.

- A. Remove dirt and foreign particles from equipment by wiping with a clean lint-free cloth, or by blowing with clean oil-free air or nitrogen.
- B. Metal parts which come in contact with oxygen and have become contaminated with grease can be cleaned as follows:
 - (1) Use a vapor degreasing method with stabilized 1,1,1 trichloroethane (manufactured by V71984) conforming to Specification MIL-T-81533. Blow clean and dry with a stream of clean, dry, oil-free air or nitrogen.

WARNING: USE 1,1,1 TRICHLOROETHANE IN A WELL VENTILATED AREA ONLY. AVOID PROLONGED OR REPEATED CONTACT WITH SKIN AND INHALATION OF TOXIC VAPORS.

4. Inspection/Check

- A. Carefully inspect all metal parts for cracks, nicks, dents, burrs or tool marks which might cause malfunction of the control unit.
- B. Inspect all wiring for broken, charred or brittle insulation, broken wires, and other signs of damage.
- C. Inspect receptacle of cable assembly (85, IPL figure 1) for broken or bent pins.
- D. Inspect solenoid (20), pressure switch (91) and pressure transducer (93) for loose terminals or other signs of damage.
- E. Inspect aneroid assemblies (41 and 63) and capsule assembly (43) for dents and cracks and other signs of damage.
- F. Inspect all filters for contamination, corrosion, or damage.
- G. Inspect all threads for burrs and signs of damage.
- H. Inspect all valve seats for scoring, scratches and other damage.
- I. Inspect all parts for obvious damage.

5. Repair

- A. Repair of parts, other than removing burrs and chasing threads, is not recommended.
- B. Replace gaskets (18, 24, 26, and 68A, IPL figure 1), preformed packings (13, 45, 76, 82, 84, 92, 99, 102, 104, 108, 121, 129, 132, 145 and 157) and diaphragms (119, 142, and 147).
- C. Replace packing (138).
- D. Replace all non-metallic parts.
- E. Replace filter screens (97, 105, 106, 109, 137, and 139).
- F. Replace all obviously defective parts.
- G. Replace P/N 25310-01, On-Off Actuation Valve Assembly with P/N 802242-01, On-Off Actuation Valve Assembly (71 through 75).

NOTE: After replacing the actuation valve assembly, place a 1/4 in. diameter yellow lacquer dot on cover subassembly (23) above plate (2).


- H. Inspect and rework, as required, pressure switch (91, IPL figure 1) manufactured by Neo-Dyne, Inc. ONLY. The namplate was cemented to the switch and inadvertently sealed the vent port which is necessary for proper altitude operation of the switch.

The serial numbers of the affected P/N 22504-7 (Boeing P/N 10-60511-3) units are listed below. Units not listed are not affected.

<u>Serial No.</u>	<u>Serial No.</u>	<u>Serial No.</u>	<u>Serial No.</u>
3115	3365	3397	3430
3144	3367	3398	3431
3150	3369	3399	3432
3151	3370	3401	3433
3152	3371	3402	3434
3156	3373	3403	3436
3159	3380	3404	3437
3330	3381	3405	3439
3331	3382	3406	3443
3334	3383	3407	3444
3337	3384	3408	3445
3341	3385	3409	3446
3346	3386	3410	3449
3352	3387	3411	3452
3353	3388	3412	3454
3356	3390	3414	3453
3357	3391	3415	
3359	3392	3416	
3360	3394	3423	
3361	3395	3426	
3362	3396	3428	

Proceed with inspection/rework as follows:

- (1) Using figure 401, carefully remove the nameplate from the pressure switch.
- (2) Add (drill or punch) a .062 to .125 diameter hole to the nameplate.
- (3) Replace the nameplate so that the vent port in the pressure switch body shows through the hole added to the nameplate.



Vent Hole Addition in Nameplate
Figure 401

22504-7, -9, -11
OVERHAUL MANUAL6. Assembly (See IPL figure 1)

NOTE: Prior to reassembling a 22504 control unit, note the dash number and determine the parts applicable to that assembly (refer to "EFFECT CODE" column of the Illustrated Parts List). Disregard any instructions that do not apply to the particular assembly being overhauled.

NOTE: If Test Stand, part number 800801-00-T53-1, is used for tests required in this paragraph, close valve (RR, figure 503A), open valve (SS), and place selector valve (PP) in 22504 (down) position. Also, disregard instructions concerning valve (B).

MATERIAL	DESCRIPTION	MANUFACTURER	REFER TO PARAGRAPH
Oxygen	MIL-O-27210, Type I	V07098	6.C. 8.
Leak Test Solution	Leak-Tek Formula 16-0X (MIL-L-25567)	V03530	6.C.(3) 6.Y.(6)
Loctite Sealant	Loctite, Grade B	V05972	6.I.(3)
Sealant	Glyptal, No. 1201	V08800	6.AK.(9)
Adhesive	Hycar Latex, No. 1562X103	V91427	9.
Oxygen Lubricant	Krytox 240 AC	V18873	6.B.(2)

NOTE: Equivalent materials may be used except for oxygen lubricant.
*Refer to paragraph 12.A.(3) for Vendor's Code

List of Consumable Materials for Assembly and Testing
Table 501

A. Assemble items 33 through 39 as follows:

- (1) Thread screw (34) into lever assembly (35) until the screw is flush with the bottom of the lever assembly.
- (2) Thread setscrew (33) into lever assembly (35) until the setscrew is flush with the top of the lever assembly.
- (3) Assemble lever assembly (35) to support (39) with pin (36), nut (37) and washer (38).


35-20-118B

Page 501
Apr 15/84

- B. Set the items assembled in step A aside, and assemble items 9 through 18 to cover subassembly (19) as follows:
- (1) Assemble gasket (18), plate (17) and lens (14) to cover subassembly (19) with screws (15) and nuts (16).
 - (2) Lubricate packing (17) sparingly with Krytox; place the packing on plunger (16) using stylus (3, figure 1002).
 - (3) Place plunger (12, IPL figure 1) with packing (13) installed through cover subassembly (19). Place washer (10) on end of plunger (12). Place spring (11) in place and thread button (9) onto plunger (12).
- C. Leak test cover subassembly (19) in accordance with figure 501 and the following procedure.

CAUTION: OXYGEN IS USED AS THE TEST GAS WHEN PERFORMING THE TESTS OUTLINED IN TESTING PARA. 8. IF NITROGEN OR AIR IS USED, APPROPRIATE DENSITY CORRECTION FACTORS SHALL BE APPLIED TO THE FLOWMETER USED.

- (1) Place unit under test in leak test fixture (5, figure 1002) and lock in place with handle.



Cover Subassembly Leak Test Setup
Figure 501

- (2) Apply 15 psi to test port.
- (3) Coat all rolled fittings and area of lens (14, IPL figure 1) with leak test solution. No leakage shall be evident; refer to figure 801 for remedial action.



22504
OVERHAUL MANUAL

- (4) After completion of test, close off oxygen pressure, remove unit from test setup, blow dry with a stream of clean, dry, oil-free air and continue assembly.
- D. Set the items assembled in step B, (1) through (3) aside, and assemble items 159 through 162 to housing assembly (163) as follows:
- (1) Attach instruction plate (159) to housing assembly (163) with screws (160).
 - (2) Attach nameplate (161) to housing assembly (163) with screws (162).
- E. Assemble items 53 through 58 to lever assembly (59) as follows:
- (1) Insert plate (56) on shaft of lever assembly (59).
 - (2) Assemble indicator (53) to lever assembly (59) with screw (54) and washer (55).
 - (3) Place washers (57) and (58) on other end of lever assembly (59).
- NOTE: Place flat side of washer (58) against washer (57).
- F. Set items assembled in step E aside.
- G. Assemble items 2 or 2A and 5 through 8 on cover subassembly (19) as follows:
- (1) Assemble identification plate (2) to cover subassembly (19) if replacement is required.
 - (2) Secure leaf (8) to cover subassembly (19) with pin (5).
 - (3) Retain pin (5) with pin (6) and washers (7).
- H. Install filter screens (105, 106 and 109) into housing assembly (163).
- I. Assemble valve assembly (123 through 128) as follows:
- (1) Place seat (126), washer (127) and guide (128) on stem (125).
 - (2) Place spring (124) in place on guide (128).
 - (3) Secure these items together by threading head (123) onto stem (125).

35-20-118B


22504
OVERHAUL MANUAL

NOTE: Apply Loctite to threads of stem (125) prior to assembly. After applying loctite rest the item on the face of head (123) and allow to dry. Allow sufficient drying time to prevent loctite from running into bore of guide (128).

- J. Coat packing (129) with distilled water and place in groove provided in housing assembly (163). Thread assembled valve assembly (123 through 128) (refer to step I) into housing assembly (163) finger tight.
- K. Assemble valve assembly (150 through 156) as follows:
- (1) Place seat assembly (156) and guide (155) on stem (154).
 - (2) Thread nut (153) onto stem (154).
 - (3) Place spring (152) and guide (151) in place and thread retainer (150) onto stem (154). Adjust retainer (150) for dimension specified in figure 502. After adjustment, tighten nut (153, IPL figure 1) against inside face of retainer (150).
 - (4) Position damper ring (148) between retainer (150) and guide (151).
- L. Place valve (158) in housing assembly (163) with concave side facing out.
- M. Place packing (157) in groove of seat assembly (156). Compress damper ring (148) and insert valve assembly (150 through 156) with damper ring in hand tool (11, figure 1002). (Major diameter of hand tool should be up.)
- N. Place the hand tool, with valve assembly and damper ring inside, into housing assembly (163, IPL figure 1) and thread the valve assembly into the housing assembly using wrench (9, figure 1002). Remove hand tool (11) from housing assembly (163, IPL figure 1) after tightening valve assembly.

NOTE: Wrench (9, figure 1002) must line up with slots in seat assembly (156, IPL figure 1) when inserted in holes of retainer (150).


- O. Assemble valve assembly (71 through 75) as follows:
- (1) Place seat (75) and spring (73) on stem (74).
 - (2) Thread nuts (71 and 72) onto stem (74). Adjust and lock nuts (71 and 72) so that the overall length from the bottom of seat (75) to the top of nut (72) is 0.788 inches.



Flow Control Valve Assembly Adjustment
Figure 502

- P. Install packing (76) on seat (75).
- Q. Place assembled valve assembly (71 through 76) (refer to steps O and P) in housing assembly (163). Thread housing (69) into housing assembly (163) using wrench (10, figure 1002).
- R. Thread a suitable test plug into housing assembly (163, IPL figure 1) in place of pressure transducer (93).
- S. Leak test the first stage of the control unit in accordance with figure 503 and the following procedure.
 - (1) Close all test stand valves and switches and connect the unit inlet to connection (S), rotating the control unit so that first stage components are facing up. Connect a 2000 psi oxygen source to connection (W). Adjust regulator (X) for an indication of 200 psi on gauge (I).
 - (2) Torque first stage components per Table 601.
 - (3) Cap the first stage area with a rubber stopper equipped with a vent tube. Apply soap water solution across vent tube, no leakage shall be evident.
 - (4) After completion of test, adjust regulator (X) to bleed pressure from test setup, remove the unit from the test stand, blow dry with a stream of clean, dry, oil-free air and continue assembly.

SCOTT
22504
OVERHAUL MANUAL




Test Stand
Figure 503

35-20-118B

Page 506
Jun 29/87

Legend for Figure 503

- A. Connection for external flowmeter
- B. Valve (HIGH FLOW/LOW FLOW)
- C. Valve ON (high) - OFF (low) flow selector
- D. Valve (bleed)
- E. Valve (vacuum)
- F. Valve (flow control)
- G. Flow Indicator
- H. Outlet Pressure Gauge (0-160 psi) (Altitude Compensated)
- I. Inlet Pressure Gauge (0-3000 psi)
- J. Outlet Pressure Gauge (0-60 psi) (Altitude Compensated)
- K. Altimeter
- L. Switch (vibrator)
- M. Voltmeter (0-10 VDC)
- N. Light (green)
- O. Switch (energize solenoid)
- P. Light (red)
- Q. Electrical Connector (to test unit)
- R. Connection (to outlet of test unit)
- S. Connection (to inlet of test unit)
- T. Vacuum Tubing (to test port of test unit)
- U. Electrical Cable (to 110 VAC outlet)
- V. Connection (to external vacuum source)
- W. Connection (to external oxygen/air/nitrogen source)
- X. Regulator (regulates oxygen/air/nitrogen to test stand)
- Y. Connection (for positive lead of 28 VDC external power source)
- Z. Connection (for negative lead of 28 VDC external power source)
- AA. Valve (volume cylinder shut-off)
- BB. Valve (back pressure)
- CC. Valve (first stage pressure)
- DD. Valve (vent)
- EE. Valve (gauge J shut-off)
- FF. Connection (to test port of test unit)
- FF₁. Gauge (0-160 psi - first stage vibrator)
- GG. Light (indicator for vibrator)
- HH. Fuse (115V vibrator circuit)
- JJ. Regulator (first stage and back pressure)
- KK. Valve (surge bleed)



Test Stand
Figure 503A

22504
OVERHAUL MANUAL

Legend for Figure 503A

- A. Connection for external flowmeter
- B. Valve (HIGH FLOW/LOW FLOW) (located on underside of deck)
- C. Valve ON (high) - OFF (low) flow selector
- D. Valve (vent)
- E. Valve (vacuum)
- F. Valve (flow control)
- G. Flow Indicator
- H. Outlet Pressure Gauge (0-160 psi) (Altitude Compensated)
- I. Inlet Pressure Gauge (0-3000 psi)
- J. Outlet Pressure Gauge (0-60 psi) (Altitude Compensated)
- K. Altimeter
- L. Switch (vibrator)
- M. Oxygen Pressure Indicator
- N. Light (green)
- O. Switch (energize solenoid)
- P. Light (red)
- Q. Electrical Connector (to unit under test)
- R. Connection (to outlet of test unit)
- S. Connection (to inlet of test unit)
- T. Vacuum Tubing (to test port of test unit)
- U. Electrical Cable (to 110 VAC outlet)
- V. Connection (to external vacuum source)
- W. Connection (to external oxygen/air/nitrogen source)
- X. Regulator (regulates oxygen/air/nitrogen to test stand)
- Y. Connection (for positive lead of 28 VDC external power source)
- Z. Connection (for negative lead of 28 VDC external power source)
- AA. Valve (volume cylinder shut-off)
- BB. Valve (back pressure)
- CC. Valve (first stage pressure)
- DD. Valve (vent)
- EE. Valve (gauge J shut-off)
- FF. Connection (to test port of test unit)
- FF1. Gauge (0-160 psi - first stage back pressure)
- GG. Light (indicator for vibrator)
- HH. Fuse (115V vibrator circuit)
- JJ. Regulator (first stage relief and back pressure)
- KK. Valve (25 LPM surge vent)
- LL. Manometer shut-off and calibration valve
- MM. 0-100 psia gauge
- OO. 0-100 psi gauge (shut-off valve)
- PP. Surge System selector valve
- QQ. Surge relay reset
- RR. 800801 Surge System shut off valve
- SS. 22504-22505 Surge System shut off valve
- TT. 985 LPM controllable orifice
- UU. Surge pressure switch
- VV. Surge solenoid valve
- WW. Surge relay
- XX. 985 LPM surge outlet

35-20-118B

- T. Assemble screw assembly (80 and 81, IPL figure 1) by inserting insert (80) into the hole provided in screw (81). Place packing (82) in groove of screw (81) using stylus (3, figure 1002).
- U. Thread screw assembly (80 and 81, IPL figure 1) into housing assembly (163) until screw assembly is flush with housing assembly (163).
- V. Place packing (121) in groove of poppet (120). Position poppet (120) on head of stem head (123). Place diaphragm assembly (119) and ring (118) in housing assembly (163). Thread retainer (117) into the housing assembly using wrench (4, figure 1002) and torque per Table 601.
- W. Thread screw (110, IPL figure 1) into cap (111). Top of screw (110) must be flush with outside surface of cap (111) at this point in assembly. Clean off any metal particles which may have been generated by the assembly.
- X. Place ring (116), spring (115) and ring (114) in housing assembly (163). Thread cap (111) into the housing assembly using wrench (4, figure 1002).
- Y. Adjust the first stage pressure and leak test actuation valve assembly (71 through 75, IPL figure 1) in accordance with figure 503 and the following procedure.
- (1) Connect the control unit to connection (S) and connection (R) of the test stand. Connect connection (FF) to test port of unit under test. Close all other test stand valves and switches. Adjust regulator (X) for an indication of 2000 psi on gauge (I).
 - (2) Adjust adjustment cap (111, IPL figure 1) for an indication of 90 psi on gauge (FF₁).
- NOTE: Use wrench (4, figure 1002) to adjust the adjustment cap (111, IPL figure 1).
- (3) Pour sufficient distilled water into housing assembly (163) port to cover actuation valve assembly (71 through 75). No leakage shall be evident.
- NOTE: Drain excess water, blow dry with a stream of clean, dry, oil-free air.

- (4) After adjustment, exercise flow control valve assembly (150 through 156) several times. Check gauge (FF₁) for an indication of 90 psi. First stage pressure shall remain at 90 psi after exercising the flow control valve assembly.

NOTE: If first stage pressure cannot be set at 90 psi, refer to figure 801 for remedial action.

- (5) Open valve (CC) and adjust regulator (JJ) for an indication of 140 psi on gauge (FF₁).
- (6) Apply a leak test solution to adjustment cap (111, IPL figure 1) holes and adjust screw (110) for bubble leak at adjustment cap (111) holes.
- (7) Place valve (DD) on long enough to reduce pressure indication on gauge (FF₁) to 120 psi and readjust regulator (JJ). No leakage shall be evident at adjustment cap (111).

NOTE: Recheck first stage pressure for 90 psi indication on gauge (FF₁). Repeat steps (2) through (5) until proper pressures are attained.


- (8) After completion of test, close valve (CC), place valve (DD) on long enough to bleed gauge (FF₁) and continue assembly.

- Z. Place washer (42) on aneroid assembly (41). Thread the aneroid assembly into housing assembly (163) until the aneroid assembly bottoms securely on washer (42).
- AA. Position spring frame (66) and the same number of shims (68A) as were removed on housing assembly (163) aligning mounting holes of spring frame with holes in housing assembly. Thread alignment tool (12, figure 1002) through the large diameter hole in spring frame (66, IPL figure 1) and into the hole provided for aneroid assembly (63) in housing assembly (163). Thread the alignment tool into the hole until the tool bottoms out on the surface of housing assembly (163).
- AB. With alignment tool in place, adjust spring frame (66) until mounting holes are aligned with holes in housing assembly. Secure the spring frame to the housing assembly with screws (67) and washers (68). Unthread the alignment tool from the housing assembly.


- AC. Carefully thread aneroid assembly (63) into housing assembly (163) until it bottoms out finger tight. Mount the items assembled in step E to the housing assembly with screws (51) and washers (52).
- AD. Position leaf spring (62) between lever assembly (59) and aneroid assembly (63). Position the leaf spring so that the ends of the leaf spring line up with the slots of spring frame.
- AE. Thread one lock nut (61) onto end of tie bolt (60). Slide tie bolt (60) through holes in spring frame (66) and thread on other lock nut (61). Turn in lock nuts until ends of leaf spring (62) are in slots of spring frame (66).
- AF. Turn in lock nuts (61) until leaf spring (62) is in the "ON" position illustrated in figure 504. Adjust the lock nuts so that the leaf spring holds with a 1.2 pound load applied to lever assembly (59, IPL figure 1) and snaps to the "OFF" position when a 1.25 load is applied as illustrated in figure 504.
- AG. Thread seat assembly (49, IPL figure 1) into housing assembly (163). Place spring (48) and stem (47) into port of housing assembly. Thread nut (44) onto capsule assembly (43). Place packing (45) in groove of capsule assembly (43) using stylus (3, figure 1002). Using a sharp scriber, draw a scratch across seating area of seat assembly (49) prior to installation.
- AH. Insert pin (46, IPL figure 1) into capsule assembly (43); then thread the capsule assembly into housing assembly (163) until packing (45) seats in groove provided in housing assembly (163).
- AI. Install suitable test plugs in the pressure switch and actuation valve ports.
- AJ. Install insert (65) and setscrew (64) into housing assembly (163), do not tighten.
- AK. Adjust the partially assembled control unit in accordance with figure 503 and the following procedure.
- (1) Connect the control unit to the test stand at connection (S) and connection (R). Close all test stand valves and switches.

500II

22504
OVERHAUL MANUAL



ON POSITION



OFF POSITION

Leaf Spring Adjustment
Figure 504

35-20-118B

**22504
OVERHAUL MANUAL**

- (2) Connect a vacuum source to connection (V) and plug test stand into 110 VAC outlet at connection (U).
- (3) Place switch (L) "ON". Light (GG) shall illuminate.
- (4) With leaf spring (62, IPL figure 1) in "OFF" position, position test cover (6, figure 1002) on control unit and attach vacuum tubing (T) to test port of test cover.

NOTE: Do not apply external pressurized oxygen to unit under test at this time.

- (5) Adjust valves (D) and (E) until automatic actuation occurs (leaf spring can be heard snapping into "ON" position). Check altimeter (K) for altitude of actuation. Actuation must occur between 13,000 and 13,300 feet for 22504-7, -9 and -13 and 13,800 and 14,100 feet for 22504-11 as indicated on altimeter (K). Adjust position of aneroid assembly (63, IPL figure 1) by trial and error until proper altitude actuation occurs.

- (6) Tighten aneroid locking setscrew (64).

NOTE: Loosen setscrew (64) for each new position of the aneroid assembly (63), retighten setscrew prior to rechecking for altitude actuation.

- (7) Adjust valves (D) and (E) for ground level. Remove test cover and manually place leaf spring in "OFF" position.

- (8) Adjust locknuts (61) until automatic actuation (leaf spring in "ON" position) occurs at 13,900 to 14,100 feet for 22504-7, -9 and -13 and 14,500 to 14,700 for 22504-11. (Use test cover and valves (D) and (E) to determine altitude of actuation). Adjust locknuts (61) by trial and error until proper automatic actuation occurs.

- (9) Adjust valves (D) and (E) for ground level and place switch (L) in "OFF" position. Remove test cover and manually place leaf spring in "OFF" position. Apply Glyptal, or an equivalent, to locknuts (61) after final adjustment.

- (10) Remove unit from test stand and continue assembly.

22504-7, -9, -11
OVERHAUL MANUAL

AL. Place diaphragm (147) and washer (146) into housing assembly (163). Place packing (145) in groove of body (144). Insert body (144) in housing assembly (163) and depress to seat firmly on washer (146).

AM. Assemble orifice and diaphragm assembly (136 through 143) as follows:

- (1) Place diaphragm (142) and ring (141) on orifice assembly (143) and secure in place with nut (140).
- (2) Place screen (139), 1 to 3 strands of 2-1/4" long packing (138) and screen (137) into orifice assembly (143). Secure these items in the orifice assembly with setscrew (136).

NOTE: Prior to installing assembled orifice and diaphragm assembly (136 through 143) into body (144), adjust packing (138) for restriction to oxygen flow. Connect assembled orifice and diaphragm assembly to an external oxygen supply, apply 90 psi and adjust setscrew (136) until 0.16 lpm flow is attained. Stake setscrew (136) in two places.

AN. Place assembled orifice and diaphragm assembly (136 through 143) in body (144).

AO. Place spring (134) and disc (133) in cap (131). Place packing (132) in groove of cap (131).

AP. Thread cap (131) into housing assembly (163) firmly against orifice assembly (143) using wrench (7, figure 1002). Thread nut (130, IPL figure 1) onto cap (131) using wrench (8, figure 1002) and torque per Table 601.


NOTE: Hold cap (131, IPL figure 1) while tightening nut (130). Tighten nut (130) firmly against housing assembly (163).

AQ. Mount the items assembled in step A to housing assembly (163) as follows:

- (1) Place spring (40) over setscrew (33).
- (2) Mount support (39) to housing assembly (163) with screws (30) and washers (31 and 32).

NOTE: Before tightening screws (30), align center of screw (34) with tip of capsule assembly (43), and center of rivet of lever assembly (35), with tip of aneroid assembly (41).

- (3) Press lever assembly downward at aneroid assembly and tighten nut (see figure 505).
 - (4) Slightly loosen nut, until lever assembly tilts toward capsule assembly.
- AR. Adjust and test the partially assembled control unit in accordance with figure 503 and the following procedure.
- (1) Connect the control unit to the test stand at connection (R), connection (S), and connection (FF).
 - (2) Install a test plug in the relief valve port.
 - (3) Place valve (B) in "HIGH FLOW" position; place valve (C) in "ON" position; close all other valves; turn all switches off.
 - (4) Connect a 2000 psi oxygen source to connection (W); a vacuum source to connection (V); and plug connector (U) into a 110 volt AC outlet.
 - (5) Turn vibrator switch (L) on. Light (GG) shall illuminate.



Lever Assembly Adjustment
Figure 505

5000

**22504
OVERHAUL MANUAL**

- (6) Slowly turn on external oxygen supply and adjust regulator (X) for 600 psig indication on gauge (I).
- (7) Manually snap leaf spring (62, IPL figure 1) to "ON" position. The control unit shall surge as indicated on gauge (H). Open valve (F), if pressure gauge (H) remains near first stage pressure, leave valve (F) open slightly and adjust screw (81) (clockwise) until pressure indication drops on gauge (H). Keep adjusting screw (81) until only a slight flow is heard at outlet of stand.
- (8) Adjust regulator (X) for 1000 psi indication on gauge (I).
- (9) Close valve (F), place valve (B) in "HIGH FLOW" position and place valve (C) in "OFF" position. Attach a flowmeter to connection (A). Open valve (F) and adjust pilot flow adjusting screw assembly (80 and 81) for an indication of 1.3 lpm on flowmeter. Close valve (F) and remove flowmeter from connection (A).
- (10) Place valve (B) in "LOW FLOW" position, place valve (C) in "OFF" position, and place switch (EE) on. Loosen nut (44) and adjust capsule assembly (43) clockwise for 3.5 to 4.5 psi indication on gauge (J), while adjusting valve (F) for an indication of 10 lpm on flow indicator (G). Lock capsule assembly (43) with nut (44). Recheck gauge (J) for 3.5 to 4.5 psi after locking the capsule assembly. Readjust if required. Close switch (EE).
- (11) Turn adjusting screw (clockwise) until a clearance of 0.001 inch is attained between adjusting screw and capsule assembly (see figure 505).
- (12) Manually reset leaf spring (62, IPL figure 1). Place valve (B) in "HIGH FLOW" position, place valve (C) in "ON" position. Close valve (F). Attach vacuum tubing (T) to test port of test cover (6, figure 1002) and place the test cover on the control unit. Close valve (D) and open valve (E) until control unit surges. The control unit shall surge between 13,250 and 14,500 feet for 22504-7, 22504-9 and 22504-13 and between 14,000 and 15,000 feet for 22504-11, as indicated on altimeter (K).

35-20-118B

22504
OVERHAUL MANUAL

- (13) Close valve (E), open valve (D) and bleed the system by opening valve (F). Manually reset leaf spring (62, IPL figure 1). Open valves (KK and AA), close valve (D) and adjust valve (E). While adjusting valve (E), watch gauge (H). Using a stop watch, check the time elapsed from control unit turn on (surge) until the surge reaches 50 psi. Time elapsed shall be a maximum of 4 seconds.

NOTE: If time elapsed is more than 4 seconds, or a minimum of 50 psi is not attained, check for 0.001 clearance (figure 505) or replace packing (138, IPL figure 1) and adjust setscrew (136). After any adjustment of setscrew (136) repeat step (11) to insure elapsed time of 4 seconds maximum.

- (14) Close valve (KK) and bleed the system by opening valve (F). Close valve (F) and adjust valve (E) for 20,000 feet indication on altimeter (K), open valve (EE) and check indicated pressure on gauge (J). Pressure shall be between 10.8 and 13.8 psig for 22504-7, -9, -11 and 13.6 and 16.7 psig for 22504-13 with a low outlet flow.


NOTE: If pressure is low, back-off on setscrew and turn-in adjusting screw (while maintaining the 0.001 clearance between adjusting screw and capsule assembly) until pressure is between 10.8 and 13.8 psig for 22504-7, -9, -11 and 13.6 and 16.7 psig for 22504-13 as indicated on gauge (J). Reverse the adjustment procedure for decreasing the pressure (see figure 505).

- (15) Place valve (C) in "ON" position and place valve (B) in "HIGH FLOW" position. Adjust valve (E) for 20,000 feet on altimeter (K). Open valve (F) until gauge (H) indicates pressure below 60 psi, open valve (EE) to actuate gauge (J). Place valve (C) in "OFF" position and place valve (B) in "LOW FLOW" position. Adjust valve (F) for an indication of 10 lpm on flow indicator (G). Read pressure indication on gauge (J) and record on graph paper prepared in accordance with figure 506 for part numbers 22504-7, -9 and -11 and figure 506A for part number 22504-13.

- (16) Close valve (F) and adjust valve (E) for 30,000 feet on altimeter (K). Adjust valve (F) for an indication of 10 lpm on flow indicator (G). Read pressure indication on gauge (J) and record on graph paper.


- (17) For 22504-7, -9 and -11 ONLY close valve (F) and adjust valve (E) for 40,000 feet on altimeter (K). Adjust valve (F) for an indication of 10 lpm on flow indicator (G). Read pressure indication on gauge (J) and record on graph paper. Close valve (F) and open valve (D) until altimeter (K) indicates ground level. Close valve (F) and bleed system.
- (18) Draw a line between the pressure indications recorded in steps (15), (16) and (17). This line shall be parallel with the desired slope.

NOTE: If the angle of the line drawn is greater than the angle of the desired slope, loosen screws (30, IPL figure 1) and adjust support (39) in the direction of aneroid assembly (41) and tighten screws (30). If the angle is less than the angle of the desired slope, adjust support away from the aneroid assembly (41). Repeat steps (15) through (17) until desired slope is achieved. After desired slope is achieved mark support (39) position on housing assembly (163) in order to reposition the support if moved for any reasons.



Graph for Part Numbers 22504-7, -9 and -11
Figure 506

**22504
OVERHAUL MANUAL**



Graph for Part Number 22504-13
Figure 506A

- (19) For 22504-7, -9 and -11 ONLY close valve (F). Place valve (C) in "OFF" position and place valve (B) in "LOW FLOW" position. Adjust valve (E) for 40,000 feet on altimeter (K). Adjust valve (F) for 10 lpm on flow indicator (G). Gauge (J) shall indicate below 54.0 psi.
- (20) For 22504-7, -9 and -11 ONLY place valve (C) in "ON" position and place valve (B) in "HIGH FLOW" position. Adjust valve (F) for an indication of 1000 lpm on flow indicator (G). Gauge (J) shall indicate above 50 psi.
- (21) Close valve (E), open valve (D) until 20,000 feet is indicated on altimeter (K).
- (22) Place valve (C) in "ON" position and place valve (B) in "HIGH FLOW" position. Adjust valve (F) for an indication of 430 lpm on flow indicator (G). Gauge (J) shall indicate above 10.8 psi for 22504-7, -9 and -11 and above 13.6 psi for 22504-13. Close valve (E), open valve (D) and return to ground level.

35-20-118B

22504
OVERHAUL MANUAL

- (23) Close valves (F), (AA) and (EE). Open valve (BB). Adjust regulator (JJ) for an indication of 140 psi on gauge (H). With a 2000 psi indication on gauge (I), hold in this condition for two minutes. After two minutes, close valve (BB), slowly open valve (F), open valve (AA) until gauge (H) indicates zero.
- (24) Repeat steps (15) through (22). If any adjustment of screws (33 and 34) is required, repeat step (23), then steps (15) through (22).

NOTE: Steps (15) through (22) must be repeated until unit functions properly after accomplishing step (23).

- (25) Turn off all valves and switches, remove the unit from the test stand, remove all test plugs and fittings and complete assembly.

- AS. Place packing (92) on pressure switch (91) and thread the pressure switch into housing assembly (163).
- AT. Thread detent assembly (50) into housing assembly (163) maintaining a clearance of 0.02 to 0.03 inches between the top of detent assembly (50), which is above flush, and housing assembly (163).
- AU. Mount cover subassembly (19) and gaskets (24 and 26) to housing assembly (163) using screws (3) and washers (4).
- AV. Mount solenoid (20) to housing assembly (163) using screws (21) and washers (22).

NOTE: Place tubing (25) over leads of solenoid (20) after mounting to housing assembly.

- AW. Place ring (100), packing (99), sleeve (98) and screen (97) on inlet of pressure transducer (93). Secure the pressure transducer to housing assembly (163) with screws (94) and washers (95, 96 and 96A).

NOTE: Use pressure transducer, serial number 400 and subsequent only, in the control unit.

- AX. Mount cable assembly (85) to housing assembly (163) with screws (86) and washers (87).
- AY. Place disc (90) in position on pressure switch (91), then position washers (91A) on terminals of pressure switch (91).

SCOTT
22504
OVERHAUL MANUAL

AZ. Perform a transducer voltage check as follows:

- (1) Connect transducer to a regulated oxygen supply.

CAUTION: TURN POWER SUPPLY TO "OFF" POSITION PRIOR TO CONNECTING OR DISCONNECTING THE TRANSDUCER UNDER TEST.

- (2) Connect transducer (terminals 1 and 3) to a regulated 28 volt DC supply (positive lead to terminal 3, negative lead to terminal 1).

NOTE: Use an instrument with an input impedance which is not less than 50,000 ohms and whose accuracy is \pm 0.05% or better.

- (3) Measure the output voltage (terminals 1 and 2) at the various inlet pressures as shown in Table 502.

INLET PRESSURE PSI	D.C. VOLTAGE
500	1.036 to 1.204
1000	2.156 to 2.324
1500	3.276 to 3.444
2000	4.396 to 4.564

Transducer Voltage Test
Table 502


BA. Attach leads of cable assembly (85) to pressure transducer (93), pressure switch (91) and leads of solenoid (20) in accordance with figure 507.

NOTE: Use parallel connectors (23, IPL figure 1) to secure leads of solenoid (20) to appropriate leads of cable assembly (85).

BB. Secure mounting plate (27) to housing assembly (163) with screws (28) and washers (29).

BC. Place packing (84) on plug (83) using stylus (3, figure 1002).

22504 OVERHAUL MANUAL



Cabling Diagrams
Figure 507

35-20-118B

5000

22504

OVERHAUL MANUAL

- BD. Place packing (102, IPL figure 1) on relief valve (101); place packing (104) on union (103); place packing (108) on fitting (107).
- BE. Thread plug (83), relief valve (101), union (103) and fitting (107) into housing assembly (163).
- BF. Place insert (113) and setscrew (112) in housing assembly (163) to lock cap (111) in place.

NOTE: Subsequent to completion of assembly and testing, place a 1/4 in. blue lacquer dot on cover subassembly (19) above plate (2).

35-20-118B

Page 524
Jun 29/87

7. Fits and Clearances

- A. Table 601 presents the torque values necessary to assemble the unit.

UNIT	TORQUE (Newton meters)
Retainer (117, IPL figure 1) 1st stage components (123 through 128) Nut (130)	135 pound-inches (15, 3) 225 pound-inches (25, 4) 70 pound-inches (7, 9)

Assembly Torque Values
Table 601


8. Testing

CAUTION: OXYGEN IS USED AS THE TEST GAS WHEN PERFORMING THE TESTS OUTLINED IN THIS PARAGRAPH. IF NITROGEN OR AIR IS USED, APPROPRIATE DENSITY CORRECTION FACTORS SHALL BE APPLIED TO THE FLOW METER USED.

NOTE: If Test Stand, part number 800801-00-T53-1, is used for performing testing procedures, close valve (RR, figure 603A), open valve (SS), and place selector valve (PP) in 22504 (down) position. Also, disregard instructions concerning valve (B).


A. Perform a dielectric test of the assembled control unit in accordance with figure 701 and the following procedure:

- (1) Insert plug of dielectric tester into receptacle of cable assembly (85, IPL figure 1).
- (2) Connect probe A to ground terminal of tester.
- (3) Attach probe B of tester to terminal 1 for a period of two seconds. No breakdown shall be evident.
- (4) Repeat step (3) with probe B attached to terminals 2 through 8 respectively for P/N 22504-7 and 22504-11 or terminals 2 through 5 for P/N 22504-9 and 22504-13.
- (5) After test remove the control unit from the test setup




Dielectric Test
Figure 701

- B. Functionally test the assembled control unit in accordance with the following procedures.
- (1) Perform an external leakage test (at simulated operating condition) in accordance with figure 702 and the following procedure.
 - a. Place the unit in a sealed chamber and apply 2000 psi to the inlet and 65 psi to the outlet.
 - b. External leakage shall not exceed 0.020 lpm as indicated on flowmeter.
 - (2) Perform an internal leakage test (at non-operating conditions) in accordance with figure 703 and the following procedure.
 - a. Place the unit in a sealed chamber and apply 2000 psi to the inlet with the outlet vented.
 - b. Leakage shall not exceed 0.010 lpm (10 cc's per minute) as indicated on flowmeter.



External Leak Test Setup
Figure 702

- (3) Perform a first stage relief valve test in accordance with figure 703 and the following procedure.
- Close all valves and switches on test stand.
 - Connect high pressure oxygen supply (2000 psi) to connection (W) of test stand. Connect vacuum supply to connection (V). Connect electrical cable (U) to 110 VAC outlet, and connect 28 volt DC power supply to terminals (Y) and (Z).
 - Remove plug (83, IPL figure 1) from control unit.
 - Connect control unit to test stand at inlet connection (S), outlet connection (R) and test port connection (FF).



Internal Leak Test Setup
Figure 703

225D4-7, -9, -11
OVERHAUL MANUAL

- e. Open valve (CC). Gradually raise pressure with regulator (JJ) until relief valve relieves through holes of adjustment cap (111). The control unit shall relieve at 140 ± 10 psi as indicated on gauge (FF₁).
 - f. Using regulator (JJ) reduce pressure to 120 psi. Attach a suitable cc flowmeter to adjustment cap (111). Leakage shall not exceed 0.010 lpm (10 cc's per minute) as indicated on cc flowmeter.
 - g. Close valve (CC) and open valve (DD) to bleed system. Remove external cc flowmeter. Close all test stand valves and switches, replace plug (83, IPL figure 1), and continue testing.
- (4) Perform an outlet relief valve test in accordance with figure 703 and the following procedure.
- a. Remove relief valve (101, IPL figure 1) cap.
 - b. Close valves (AA) and (F), open valve (BB) and gradually raise pressure with regulator (JJ) until outlet relief valve cracks. The working pressure as indicated on gauge (H) shall be 120 ± 10 psi.
 - c. Raise pressure with regulator (JJ) to 135 psi as indicated on gauge (H). Valve shall flow freely.
 - d. Reduce pressure to 80 psi. Attach an external cc flowmeter to relief valve (101). Leakage through the relief valve shall not exceed 0.010 lpm (10 cc's per minute) as indicated on external cc flowmeter.
 - e. Remove external cc flowmeter. Close valve (BB) and open valves (AA) and (F) to bleed system. Close all test stand valves and switches. Replace relief valve cap.
- (5) Perform a flow test in accordance with figure 703 and the following procedure.
- a. Place valve (B) in "HIGH FLOW" position; valve (C) in "ON" position and open valve (AA); close all other valves; turn switch (L) off.

- b. Connect a 2000 psi oxygen source to connection (W); a vacuum source to connection (V); a 28 volt DC source to connection (Y) and (Z) and plug connector (U) into a 110 volt AC outlet.

NOTE: Do not energize the 28 volt power supply at this time.

- c. Connect the control unit to outlet (R) and inlet (S) of the test stand. Plug connector (Q) to the receptacle of the control unit. Attach vacuum tubing (T) to the test connection provided on the cover of the control unit.
- d. Energize the 28 volt DC power supply and turn vibrator switch (L) "ON".
- e. Slowly turn on external oxygen supply and regulate with regulator (X) for 2000 psi indication on gauge (I). Green light (N) shall illuminate and meter (M) shall indicate 4.5 volts DC or approximately 2000 psi.

NOTE: Meter (M) will indicate volts DC on some test stands and psi on others. Use appropriate dimension. Meter (M) indication is only approximate and denotes that the transducer is functioning. To determine actual performance, refer to paragraph 6, step AZ.

- f. By adjusting valves (D) and (E), slowly raise altitude applied to the control unit until it surges. The control unit shall surge at an altitude of 13,250 to 14,500 feet for 22504-7, -9 and -13 and at 14,000 to 15,000 for 22504-11. The surge pressure shall reach 50 psi minimum indication on gauge (H) in not more than 4 seconds. Green light (N) shall extinguish and red light (P) shall illuminate.
- g. For 22504-7, -9, -11 ONLY, after pressure surge, adjust valves (D and E) for an indication of 40,000 feet on altimeter (K). Adjust valve (F) and allow pressure indication on gauge (J) to stabilize.
- h. For 22504-7, -9, -11 ONLY, close valve (F). Place valve (B) in "LOW FLOW" position and place valve (C) in "OFF" position.

22504
OVERHAUL MANUAL

- i. For 22504-7, -9, -11 ONLY, adjust valves (D) and (E) for an indication of 40,000 feet on altimeter (K). Adjust valve (F) for a flow of 10 lpm as indicated on flow indicator (G). Gauge (J) shall indicate 50.0 to 54.0 psi.
- j. For 22504-7, -9, -11 ONLY, place valve (B) in "HIGH FLOW" position and place valve (C) in "ON" position.
- k. For 22504-7, -9, -11 ONLY, adjust valve (F) for a flow of 1000 lpm as indicated on flow indicator (G). Gauge (J) shall indicate 50.0 to 54.0 psi. Adjust valve (F) for a flow of 10 lpm on flow indicator (G) and repeat step g.
- l. Adjust valves (D) and (E) for an indication of 30,000 feet on altimeter (K). Adjust valve (F) for a flow of 10 lpm as indicated on flow indicator (G). Gauge (J) shall indicate 34.3 to 37.5 psi for 22504-7, -9, -11 and 37.0 to 40.3 psi for 22504-13.
- m. Repeat step j and adjust valve (F) for a flow of 770 lpm as indicated on flow indicator (G). Gauge (J) shall indicate 34.4 to 37.5 psi for 22504-7, -9, -11 and 37.0 to 40.3 psi for 22504-13. Adjust valve (F) for a flow of 10 lpm on flow indicator (G) and repeat step h.
- n. Adjust valves (D) and (E) for an indication of 20,000 feet on altimeter (K). Adjust valve (F) for a flow of 10 lpm as indicated on flow indicator (G). Gauge (J) shall indicate 10.8 to 13.8 psi for 22504-7, -9, -11 and 13.6 to 16.7 psi for 22504-13.
- o. Repeat step j. Adjust valve (F) for a flow of 430 lpm as indicated on flow indicator (G). Gauge (J) shall indicate 10.8 to 13.8 psi for 22504-7, -9, -11 and 13.6 to 16.7 psi for 22504-13. Adjust valve (F) for 10 lpm flow as indicated on flow indicator (G) and repeat step h.
- p. Adjust valves (D) and (E) for an indication of 12,000 feet on altimeter (K). Manually depress lever assembly (8, IPL figure 1) on the control unit. Control unit indicator shall indicate "OFF", red light (P) extinguishes and green light (N) illuminates. Open valve (F) and bleed system. Close valve (F).

22504
OVERHAUL MANUAL

- q. Adjust valves (D) and (E) for an indication of 10,000 feet on altimeter (K). Energize (raise) switch (O). Unit shall surge, green light (N) shall extinguish, and red light (P) shall illuminate.
- r. Adjust valves (D) and (E) for ground level. Allow outlet pressure on gauge (J) to stabilize.
- s. Adjust valve (F) for a flow of 10 LPM and repeat step h.
- t. Adjust valve (F) for a flow of 10 LPM. Gauge (J) shall indicate 2.25 to 5.4 psi for 22504-7, -9, -11 and 5.0 to 8.2 psi for 22504-13.
- u. Repeat step j and adjust valve (F) for a flow of 230 LPM. Gauge (J) shall indicate 2.25 to 5.4 psi for 22504-7, -9, -11 and 5.0 to 8.2 psi for 22504-13. Close valve (F).
- v. Manually depress the reset mechanism on the control unit and release. Open valve (F) and slowly bleed the system. Control unit indicator shall indicate "OFF"; red light (P) shall extinguish and green light (N) shall illuminate.
- w. Close valve (F) and regulate external pressure supply with regulator (X) to 1000 psi as indicated on gauge (I).
- x. Place valve (B) in "HIGH FLOW" position; place valve (C) in "ON" position.
- y. Repeat steps f, p, q and v.
- z. Close valve (F) and regulate external pressure supply with regulator (X) to 300 psi as indicated on gauge (I).
- aa. Repeat steps f, p, q and v.
- ab. Close all valves, turn off or disconnect all pressure and electrical connections and remove control unit from test stand.

9. Trouble shooting

A. See figure 801 for trouble shooting chart.

TROUBLE	PROBABLE CAUSE	REMEDY
Leakage evident when leak testing cover subassembly (19, IPL figure 1) (refer to Assembly, step C)	Faulty rolled fittings	Seal leaks by applying Hycar adhesive to joints of rolled fittings
	Screws (15, IPL figure 1) not tight enough	Tighten screws
	Faulty gasket (18)	Replace gasket
	Damaged cover subassembly (19)	Replace cover sub-assembly
Leakage evident when leak testing first stage components (refer to Assembly, step S)	Faulty packing (129)	Replace packing
	Scored, scratched or damaged seat (126)	Replace valve seat
	Pressure reducer valve assembly (123 through 128) loose in housing assembly (163)	Tighten pressure reducer valve assembly
	Contamination in valve seat area	Clean contaminated area
Unable to set up first stage pressure (refer to Assembly, step Y)	Punctured or damaged diaphragm assembly (119)	Replace diaphragm assembly
	Faulty spring (115)	Replace spring
	Spring (115) not seating properly	Check seating of spring
	Leakage at flow control valve assembly (150 through 156)	Replace packing (157, IPL figure 1); replace valve (158)

Trouble Shooting Chart (Sheet 1 of 3)
Figure 801

35-20-118B

22504 OVERHAUL MANUAL

TROUBLE	PROBABLE CAUSE	REMEDY
Leakage evident when leak testing actuation valve assembly (71 through 75)	Scored, scratched or damaged seat (75)	Replace valve seat
	Scratched or damaged stem (74)	Replace stem
	Housing (69) loose	Tighten housing
	Valve seat in housing assembly (163) scratched	Repair or replace assembly
Control unit fails to surge between 13,250 and 14,500 feet for 22504-7, -9 and -13 & between 14,000 and 15,000 for 22504-11	Aneroid assembly (63) not adjusted properly	Adjust aneroid assembly per Assembly, step AK
	Faulty aneroid assembly (63)	Replace aneroid assembly
Outlet pressure of control unit fails to stabilize at the proper pressure after initial pressure surge	Capsule assembly (43) not adjusted properly	Adjust capsule assembly per Assembly, step AR (10)
	Leakage at surge valve	Replace defective parts
	Faulty capsule assembly (43)	Replace capsule assembly
	Pilot flow out of adjustment	Adjust screw (81)
Outlet pressure of control unit fails to stabilize at the proper pressure at altitude	Screw assembly (34) not properly adjusted	Adjust setscrew per Assembly, step AR (11)
Surge time exceeds 4 seconds maximum	Orifice and diaphragm assembly (136 through 143) not adjusted properly	Adjust orifice and diaphragm assembly per Assembly, step AM (2)
Unable to obtain proper slope	Support (39) not positioned properly	Position support per Assembly, step AR (18)

Trouble Shooting Chart (Sheet 2 of 3)
Figure 801

TROUBLE	PROBABLE CAUSE	REMEDY
Unit fails to turn on electrically	Faulty solenoid (20)	Replace solenoid
	Faulty cable assembly (85)	Replace cable assembly
	Faulty connection of electrical leads	Check connection at connectors (23)
	Detent assembly (50) out of adjustment	Adjust detent assembly
With inlet pressure applied, green light on test stand fails to illuminate	Faulty connection of electrical leads	Check connection
	Faulty pressure switch (91)	Replace pressure switch
	Faulty cable assembly (85)	Replace cable assembly
Control unit fails to meet requirements of Testing, step B (3)	Adjusting screw (110) not adjusted properly	Adjust screw per Assembly, step Y (6)
	Faulty diaphragm assembly (119)	Replace diaphragm assembly
Control unit fails to meet requirements of Testing, step B (4)	Faulty outlet relief valve (101)	Replace outlet relief valve

Trouble Shooting Chart (Sheet 3 of 3)
Figure 801

10. Storage Instructions


- A. Cap inlet and outlet fittings and electrical receptacle with protective closures.
- B. Wrap the control unit to prevent dust or other foreign matter from entering. Do not use any preservative coating on the control unit.

11. Special Tools, Fixtures and Test Equipment

- A. All special tools, fixtures and test equipment required to overhaul the control unit are listed in figure 1001 and illustrated in figure 1002 and are manufactured by Scott Aviation.

FIGURE 1002 ITEM NO.	PART NUMBER	PART NAME	APPLICATION
1	22504-1-T53-1 or 800801-00- T53-1	TEST STAND	Used to test the control unit
2	22504-1-T53-2	DIELECTRIC TESTER	Used to dielectric test cable assembly (85, IPL figure 1)
3	22505-T52-1	STYLUS	Used to install performed packings (13, 45, 82 and 84)
4	24661-T91-1	WRENCH	Used to remove/install cap (111) and retainer (117)
5	25682-1-T58-1	LEAK TEST HOLDING FIX- TURE	Used to leak test cover sub- assembly (19)
6	25682-T58-2	TEST COVER	Used during reassembly test- ing
7	25694-T91-1	WRENCH	Used to remove/install cap (131)
8	25695-T91-1	WRENCH	Used to remove/install lock nut (130)
9	25880-T91-1	WRENCH	Used to remove/install valve assembly (150 through 156)
10	26164-T91-1	WRENCH	Used to remove/install housing (69)
11	800376-T52-1	SPECIAL HAND TOOL	Used to install valve assembly (150 through 156)
12	10000728-T52-1	ALIGNMENT TOOL	Used to align frame (66) with housing assembly (163)

Special Tools, Fixtures and Test Equipment List
Figure 1001



Special Tools, Fixtures and Test Equipment
Figure 1002

12. Illustrated Parts List

A. This Illustrated Parts List lists and describes the parts of the 22504-7, 22504-9, 22504-11 and 22504-13 Electro-Pneumatic Continuous Flow Control Units.

- (1) The Illustrated Parts List consists of a parts listing and a completely indexed exploded view drawing. Each assembly listed is followed immediately by its component parts, properly indented thereunder, to show their relationship to the assembly.
- (2) The quantities listed in the "UNITS PER ASSY" column are the total quantity used per control unit at the location indicated.
- (3) The parts numbers listed in the "PART NUMBER" column are Scott Aviation part numbers except standard parts, which are listed by "AN" and "MS" part numbers, and vendor parts, which are listed by vendor part numbers. The following list contains the code and name and address of the vendors supplying items for the control unit.

CODE	VENDOR'S NAME AND ADDRESS
V02697	Parker Seal Co. Division of Parkerhannfin Corp. Lexington, Kentucky
V03520	American Gas & Chemicals, Inc. New York, New York
V05972	Loctite Corp. Newington, Connecticut
V07098	Union Carbide Corp. Linde Division Tonawanda, New York
V07322	Minnesota Rubber Co. Minneapolis, Minnesota
V08800	General Electric Co. Insulating Materials Dept. Schenectady, New York
V18873	E.I. DuPont DeNemours & Co., Inc. Wilmington, Delaware
V71984	Hooker Chemical Corp. Niagara Falls, New York

35-20-118B

**22504
OVERHAUL MANUAL**

CODE	VENDOR'S NAME AND ADDRESS
V75237	B.F. Goodrich Chemical Co. Cleveland, Ohio
V75237	The Kaynar Co. Division of Reiner Industries Inc. Pico Rivera, California

- (4) Parts used on only one part number control unit are indicated by letter symbol immediately following the description of a part in the "EFFECT CODE" column. In cases where the "EFFECT CODE" column has been left blank, parts listed are common to all control units.


PART NUMBER	EFFECT CODE
22504-7	A
22504-9	B
22504-11	C
22504-13	D

- (5) A Numerical Index has been provided at the conclusion of the Group Assembly Parts List. Part numbers have been arranged in accordance with Specification ATA 100.

B. How to use this Illustrated Parts List.

- (1) If neither the part number nor the nomenclature is known, the part can be found by comparison with the exploded view illustration. When located on the illustration, the index number will refer to the line in the Group Assembly Parts List with the part number and the nomenclature.
- (2) When the part number is known, refer to the Numerical Index and find the part number. Opposite the part number is the figure and item number which refers to the Group Assembly Parts List. Proper nomenclature is opposite the item number on the Group Assembly List page.

22504
OVERHAUL MANUAL



Electro-Pneumatic Continuous Flow Control Unit
Figure 1

35-20-118B

22504
OVERHAUL MANUAL

FIG. ITEM	PART NUMBER	AIRLINE STOCK NO.	NOMENCLATURE 1234567	EFF CODE	UNITS PER ASSY	
1-1	22504-7		CONTROL UNIT-CONTINUOUS FLOW-ELECTRO-PNEU	A	RF	
-1A	22504-9		CONTROL UNIT-CONTINUOUS FLOW-ELECTRO-PNEU	B	RF	
-1B	22504-11		CONTROL UNIT-CONTINUOUS FLOW-ELECTRO-PNEU	C	RF	
-1C	22504-13		CONTROL UNIT-CONTINUOUS FLOW-ELECTRO-PNEU	D	RF	R
2	25737-00		. PLATE-ID		1	
2A	10006822		. PLATE-ID	D	1	R
-2N	802956-01		. COVER ASSEMBLY (ATTACHING PARTS)		1	
3	33359-213		. SCREW		13	
4	MS35333-70		. WASHER		13	
			-----*-----			
5	MS20392-2-25		. . PIN (ATTACHING PARTS)		1	
6	MS24665-149		. . PIN		1	R
7	AN960-10		. . WASHER		2	
7A	33451-009		. . WASHER		AR	
			-----*-----			
8	25393-13		. . LEAF-LOWER		1	
9	25387-00		. . BUTTON		1	
10	MS35338-40		. . WASHER		1	
11	25380-00		. . SPRING		1	
12	10000725		. . PLUNGER		1	
13	2-5 (COMP S417-7)		. . PACKING-PREFORMED (V02697)		1	
14	25307-00		. . LENS (ATTACHING PARTS)		1	
15	AN500D2-5		. . SCREW		2	
16	23249-01		. . NUT		2	
			-----*-----			
17	25383-00		. . PLATE-LENS		1	
18	25382-00		. . GASKET-PLATE		1	
19	25682-01		. . COVER SUBASSY		1	
20	802957-01		. SOLENOID ASSY (ATTACHING PARTS)		1	
21	33359-215		. SCREW		4	
22	MS35338-40		. WASHER		4	
23	34131		. CONN-PARALLEL (USED ON 22504-7 UP TO SN 1404 & 22504-9 UNITS UP TO SN1014)		2	
			-----*-----			

- ITEM NOT ILLUSTRATED

22504
OVERHAUL MANUAL

FIG. ITEM	PART NUMBER	AIRLINE STOCK NO.	NOMENCLATURE 1234567	EFF CODE	UNITS PER ASSY
1 24	25397-00		. GASKET-VALVE LIFTER		1
25	13576-9		. TUBING-PLASTIC (USED ON ALL 22504-11 UNITS; SN1015 & SUBQ ON 22504-9 UNITS; SN 1405 & SUBQ ON 22504-7 UNITS)		1
-25A	13576-7		. TUBING-PLASTIC (USED ON 22504-7 UNITS THRU SN 1404 AND 22504-9 UNITS THRU SN 1014)	AB	1
26	24509-00		. GASKET-COVER SUBASSY		1
27	24686-00		. PLATE-MOUNTING (ATTACHING PARTS)		1
28	MS35191-272		. SCREW		4
29	MS35336-23		. WASHER -----*		4
-29A	802955-01		. LEVER ASSEMBLY (ATTACHING PARTS)		1
30	33359-228		. SCREW		2
31	MS15795-805		. WASHER		2
32	MS35333-71		. WASHER -----*		2
33	AN565FC4H10		. . SETSCREW		1
34	25488-00		. . SCREW ASSY (USED ON ALL 22504-11 and 22504-13 UNITS; SN1015 & SUBQ ON 22504-9 UNITS; SN1617 & SUBQ ON 22504-7 UNITS)		1
-34A	25292		. . SCREW ASSY (USED ON 22504-7 UNITS THRU SN1616 AND 22504-9 UNITS THRU SN1014)	AB	1

- ITEM NOT ILLUSTRATED

35-20-118B

5000

22504 OVERHAUL MANUAL

FIG. ITEM	PART NUMBER	AIRLINE STOCK NO.	NOMENCLATURE 1234567	EFF CODE	UNITS PER ASSY
1 35	25283-01		. . LEVER ASSEMBLY (ATTACHING PARTS)		1
36	25478-00		. . PIN-LEVER		1
37	23249-01		. . NUT		1
38	10001500		. . WASHER (USED ON ALL 22504-11 UNITS; SN1015 & SUBQ ON 22504-9 UNITS AND SN1617 & SUBQ ON 22504-7 UNITS)		2
-38A	AN960-3		. . WASHER (USED ON 22504-7 UNITS THRU SN1616 AND 22504-9 UNITS THRU SN1014) -----*	AB	2
39	23319-01		. . SUPPORT-LEVER		1
40	25306-00		. SPRING		1
41	23372-00		. ANEROID ASSEMBLY		1
42	MS35338-44		. WASHER		1
43	23373-00		. CAPSULE ASSEMBLY		1
44	AN316C5		. NUT-LOCK		1
45	MS9385-02		. PACKING-PREFORMED		1
46	24664-00		. PIN-PUSH		1
47	24665-00		. STEM		1
48	25308-00		. SPRING		1
49	23381-01		. SEAT ASSY-STEM		1
-49A	25885-00		. . GASKET		1
50	25384-01		. DETENT ASSEMBLY		1
-50A	802954-01		. INDICATOR ASSY (ATTACHING PARTS)		1
51	33359-213		. SCREW		2
52	MS35333-70		. WASHER -----*		2
53	25680-00		. . INDICATOR (ATTACHING PARTS)		1
54	AN520-OR3		. . SCREW		1
55	MS27183-1		. . WASHER -----*		1
56	25394-00		. . PLATE		1
57	25723-00		. . WASHER-BACK-UP		1
58	25736-00		. . WASHER-SEAL		1
59	25304-03		. . LEVER ASSY-AUTO. ACTUATION		1

- ITEM NOT ILLUSTRATED

35-20-118B

Page 1106
Jun 29/87

22504
OVERHAUL MANUAL

FIG. ITEM	PART NUMBER	AIRLINE STOCK NO.	NOMENCLATURE 1234567	EFF CODE	UNITS PER ASSY
1 60	3501-02		. BOLT-TIE (ATTACHING PARTS)		1
61	58526-00		. NUT -----*		2
62	10000726		. SPRING-LEAF		1
63	23372-00		. ANEROID ASSEMBLY (ATTACHING PARTS)		1
64	AN565AC4H4		. SETSCREW		1
65	2837-02		. INSERT -----*		1
66	10000728		. FRAME-SPRING (ATTACHING PARTS)		1
67	MS51957-13		. SCREW		3
68	MS35333-70		. WASHER -----*		3
68A	10005577		. SHIM		AR
69	26164-01		. HOUSING-VALVE ASSY		1
-70	802242-01		. VALVE ASSY-ACT.- ON-OFF		1
71	25699-00		. . NUT		1
72	25698-00		. . NUT		1
73	25481-00		. . SPRING		1
74	10873-00		. . STEM		1
75	10002506		. . SEAT		1
76	MS9068-012		. PACKING-PREFORMED		1
-77	DELETED				
-78	DELETED				
-79	25289-01		. SCREW ASSY-ADJ- PILOT FLOW		1
80	2837-01		. . INSERT		1
81	25289-03		. . SCREW		1
82	MS9068-008		. PACKING-PREFORMED		1
83	25288-00		. PLUG-TEST		1
84	MS9385-02		. PACKING-PREFORMED		1
85	25683-11		. CABLE ASSY-ELEC (USED ON 22504-7 UNITS UP TO SN1404)	A	1
85A	800798-00		. CABLE ASSY-ELEC (USED ON ALL 22504-11 UNITS AND ON SN1405 & SUBQ ON 22504-7 UNITS)	AC	1

- ITEM NOT ILLUSTRATED

35-20-118B

SCOTT

22504
OVERHAUL MANUAL

FIG. ITEM	PART NUMBER	AIRLINE STOCK NO.	NOMENCLATURE 1234567	EFF CODE	UNITS PER ASSY
1-85B	800549-00		. CABLE ASSY-ELEC (USED ON 22504-9 UNITS THRU SN1014)	B	1
-85C	800799-00		. CABLE ASSY-ELEC (USED ON ALL 22504-13 UNITS AND ON 22504-9 UNITS SN1015 & SUBQ) (ATTACHING PARTS)	BD	1
86	33359-213		. SCREW		4
87	MS35333-70		. WASHER		4
-88	MS51957-26		. SCREW	BD	1
-89	MS35333-71		. WASHER	BD	1
			-----★-----		
90	28965-00		. DISC-INSULATION (USED WITH PRESSURE SWITCH P/N 607G15, MFD BY V09049)		AR
-90A	10001928		. DISC-INSULATION (USED WITH PRESSURE SWITCH P/N CA-4001 MFD BY V17247)		AR
91	23374-00		. SWITCH-PRESSURE (THREE NUTS SUPPLIED) (ATTACHING PARTS)		1
91A	1902-00		. WASHER (V78189) (USED ON ALL 22504-11 AND 22504-13 UNITS; SN1015 & SUBQ ON 22504-9 UNITS AND SN1014 & SUBQ ON 22504-7 UNITS)		3
			-----★-----		
92	MS9385-03		. PACKING-PREFORMED		1
93	25685-00		. TRANSDUCER-PRESSURE (THREE SCREWS SUPPLIED) (ATTACHING PARTS)	AC	1
94	MS15937-34		. SCREW	AC	2
95	MS35333-71		. WASHER	AC	2
96	AN960-6L		. WASHER	AC	1
96A	1902-00		. WASHER (V78189) (USED ON ALL 22504-11 UNITS AND SN1045 & SUBQ ON 22504-7 UNITS)	AC	3

- ITEM NOT ILLUSTRATED

35-20-118B

22504
OVERHAUL MANUAL

FIG. ITEM	PART NUMBER	AIRLINE STOCK NO.	NOMENCLATURE 1234567	EFF CODE	UNITS PER ASSY
1 97	6472-82		. SCREEN-FILTER	AC	1
98	22151-01		. SLEEVE	AC	1
99	MS9068-006		. PACKING-PREFORMED	AC	1
100	22152-01		. RING-BACK-UP	AC	1
101	25603-00		. VALVE-RELIEF		1
102	MS9385-08		. PACKING-PREFORMED		1
103	MS21900-5C		. UNION		1
104	3-5 (COMP V747-75)		. PACKING-PREFORMED (V02697)		1
105	24202-01		. FILTER-SCREEN		1
106	8938-04		. FILTER-SCREEN		1
107	25886-00		. FITTING-OUTLET	ABC	1
-107A	10006807		. REDUCER-EXTERNAL THREAD	D	1
108	MS9385-08		. PACKING-PREFORMED		1
109	25711-00		. FILTER-SCREEN		1
110	24660-02		. SCREW-ADJUSTING		1
111	24661-00		. CAP-ADJUSTMENT (ATTACHING PARTS)		1
112	AN565C4H4		. SETSCREW		1
113	2837-02		. INSERT -----*-----		1
114	22549-00		. RING-SLIP		1
115	25875-00		. SPRING		1
116	22549-00		. RING-SLIP		1
117	25713-00		. RETAINER-DIAPHRAGM		1
118	10000614		. RING-THRUST		1
119	800325-00		. DIAPHRAGM ASSY		1
120	10000626		. POPPET		1
121	Q4006 (COMP 366Y)		. PACKING-PREFORMED		1
-122	25738-01		. VALVE ASSY-PRESS. RED.		1
123	25720-00		. . HEAD-STEM		1
124	10000611		. . SPRING		1
125	25719-00		. . STEM-VALVE		1
126	25602-00		. . SEAT-INLET VALVE		1
127	22764-00		. . WASHER-BACK-UP		1
128	22762-00		. . GUIDE-STEM		1
129	MS9068-013		. PACKING-PREFORMED		1
130	25695-00		. NUT-LOCK		1
131	25694-00		. CAP		1
132	MS9068-023		. PACKING-PREFORMED		1
133	25882-00		. DISC-SLIP		1
134	25286-00		. SPRING		1

- ITEM NOT ILLUSTRATED

35-20-118B

SCOTT

22504
OVERHAUL MANUAL

FIG. ITEM	PART NUMBER	AIRLINE STOCK NO.	NOMENCLATURE 1234567	EFF CODE	UNITS PER ASSY
1-135	25530-01		. ORIFICE & DIAPH ASSY		1
136	55573-00		. . SETSCREW-HEX SOCKET		1
137	8938-01		. . SCREEN-FILTER		1
138	50330-00		. . PKG-GLASS WOOL CORD		AR
139	8938-01		. . SCREEN		1
140	25532-00		. . NUT-HEXAGON		1
141	25533-00		. . RING		1
142	25883-00		. . DIAPHRAGM		1
143	25531-01		. . ORIFICE ASSY		1
144	25693-00		. BODY-PRESS. SURGE VALVE		1
145	MS9068-020		. PACKING-PREFORMED		1
146	23371-00		. WASHER-THRUST		1
147	23368-00		. DIAPHRAGM		1
148	10000736		. RING-DAMPER		1
-149	800376-00		. VALVE ASSY-FLOW CONTROL		1
150	10000734		. . RETAINER-RING		1
151	10000735		. . GUIDE-SPRING		1
152	25879-00		. . SPRING		1
153	AN340C4		. . NUT		1
154	25715-00		. . STEM-VALVE		1
155	25718-00		. . GUIDE-STEM		1
156	25724-01		. . SEAT ASSEMBLY		1
157	MS9068-015		. PACKING-PREFORMED		1
158	25722-00		. VALVE-SPOOL		1
159	25297-00		. PLATE-INST (ATTACHING PARTS)		1
160	MS21318-1		. SCREW -----*		2
161	10554-00		. PLATE-NAME (ATTACHING PARTS)		1
162	MS21318-1		. SCREW -----*		2
163	25290-01		. HOUSING ASSEMBLY	AC	1
-164	25290-11		. HOUSING ASSEMBLY	BD	1

- ITEM NOT ILLUSTRATED

35-20-118B

Page 1110
Jan 29 '87

22504
OVERHAUL MANUAL

PART NUMBER	AIRLINE PART NO.	CH-SECT-UNIT-FIG-ITEM	TTL REQ
AN316C5		35- 20 -118B- 1 44	1
AN340C4		35- 20 -118B- 1 153	1
AN500D2-5		35- 20 -118B- 1 15	2
AN520-OR3		35- 20 -118B- 1 54	1
AN565C632R4		35- 20 -118B- 1 - 88	1
AN565AC4H4		35- 20 -118B- 1 64	2
AN565FC4H10		35- 20 -118B- 1 33	1
AN960-10		35- 20 -118B- 1 7	3
AN960-3		35- 20 -118B- 1 - 38A	2
AN960-6L		35- 20 -118B- 1 96	1
MS15795-805		35- 20 -118B- 1 31	2
MS20392-2-25		35- 20 -118B- 1 5	1
MS21318-1		35- 20 -118B- 1 160	4
MS21900-5C		35- 20 -118B- 1 103	1
MS24665-149		35- 20 -118B- 1 6	1
MS27183-1		35- 20 -118B- 1 55	1
MS35191-272		35- 20 -118B- 1 28	4
MS35333-70		35- 20 -118B- 1 4	22
MS35333-71		35- 20 -118B- 1 32	5
MS35336-23		35- 20 -118B- 1 29	4
MS35338-40		35- 20 -118B- 1 10	5
MS35338-44		35- 20 -118B- 1 42	1
MS51937-13		35- 20 -118B- 1 94	2
MS51957-13		35- 20 -118B- 1 67	3
MS9068-006		35- 20 -118B- 1 99	1
MS9068-008		35- 20 -118B- 1 82	1
MS9068-012		35- 20 -118B- 1 76	1
MS9068-013		35- 20 -118B- 1 129	1
MS9068-015		35- 20 -118B- 1 157	1
MS9068-020		35- 20 -118B- 1 145	1
MS9068-023		35- 20 -118B- 1 132	1
MS9385-02		35- 20 -118B- 1 45	2
MS9385-03		35- 20 -118B- 1 92	1
MS9385-08		35- 20 -118B- 1 102	2
Q4006 (COMP 366Y)		35- 20 -118B- 1 121	1
10000611		35- 20 -118B- 1 124	1
10000614		35- 20 -118B- 1 118	1
10000626		35- 20 -118B- 1 120	1
10000725		35- 20 -118B- 1 12	1
10000726		35- 20 -118B- 1 62	1
10000728		35- 20 -118B- 1 66	1
10000734		35- 20 -118B- 1 150	1
10000735		35- 20 -118B- 1 151	1
10000736		35- 20 -118B- 1 148	1
10001500		35- 20 -118B- 1 38	2
10001928		35- 20 -118B- 1 - 90A	AR

35-20-118B

SCOTT

22504 OVERHAUL MANUAL

PART NUMBER	AIRLINE PART NO.	CH-SECT-UNIT-FIG-ITEM	TTL REQ
10002506		35- 20 -118B- 1 75	1
10005577		35- 20 -118B- 1 68A	AR
10006807		35- 20 -118B- 1 -107A	1
10006822		35- 20 -118B- 1 2A	1
10554-00		35- 20 -118B- 1 161	1
10873-00		35- 20 -118B- 1 74	1
13576-7		35- 20 -118B- 1 25A	1
13576-9		35- 20 -118B- 1 25	1
1902-00		35- 20 -118B- 1 91A	6
		35- 20 -118B- 1 96A	
2-5 (COMP S417-7)		35- 20 -118B- 1 13	1
20489-00		35- 20 -118B- 1 138	AR
22151-01		35- 20 -118B- 1 98	1
22152-01		35- 20 -118B- 1 100	1
22504-11		35- 20 -118B- 1 - 1B	RF
22504-13		35- 20 -118B- 1 - 1C	RF
22504-7		35- 20 -118B- 1 - 1	RF
22504-9		35- 20 -118B- 1 - 1A	RF
22549-00		35- 20 -118B- 1 114	2
		35- 20 -118B- 1 116	
22762-00		35- 20 -118B- 1 128	1
22764-00		35- 20 -118B- 1 127	1
23249-01		35- 20 -118B- 1 16	3
		35- 20 -118B- 1 37	
23319-01		35- 20 -118B- 1 39	1
23368-00		35- 20 -118B- 1 147	1
23371-00		35- 20 -118B- 1 146	1
23372-00		35- 20 -118B- 1 41	2
		35- 20 -118B- 1 63	
23373-00		35- 20 -118B- 1 43	1
23374-00		35- 20 -118B- 1 91	1
23381-01		35- 20 -118B- 1 49	1
24202-01		35- 20 -118B- 1 105	1
24509-00		35- 20 -118B- 1 26	1
24660-02		35- 20 -118B- 1 110	1
24661-00		35- 20 -118B- 1 111	1
24664-00		35- 20 -118B- 1 46	1
24665-00		35- 20 -118B- 1 47	1
24686-00		35- 20 -118B- 1 27	1
25283-01		35- 20 -118B- 1 35	1
25286-00		35- 20 -118B- 1 134	1
25288-00		35- 20 -118B- 1 83	1
25289-03		35- 20 -118B- 1 81	1
25289-1		35- 20 -118B- 1 -79	1
25290-01		35- 20 -118B- 1 163	1
25290-11		35- 20 -118B- 1 -164	1
25292		35- 20 -118B- 1 - 34A	1
25297-00		35- 20 -118B- 1 159	1

35-20-118B



22504
OVERHAUL MANUAL

PART NUMBER	AIRLINE PART NO.	CH-SECT-UNIT-FIG-ITEM	TTL REQ
25304-03		35- 20 -118B- 1 59	1
25306-00		35- 20 -118B- 1 40	1
25307-00		35- 20 -118B- 1 14	1
25308-00		35- 20 -118B- 1 48	1
25380-00		35- 20 -118B- 1 11	1
25382-00		35- 20 -118B- 1 18	1
25383-00		35- 20 -118B- 1 17	1
25384-01		35- 20 -118B- 1 50	1
25387-00		35- 20 -118B- 1 9	1
25393-13		35- 20 -118B- 1 8	1
25394-00		35- 20 -118B- 1 56	1
25397-00		35- 20 -118B- 1 24	1
25478-00		35- 20 -118B- 1 36	1
25481-00		35- 20 -118B- 1 73	1
25488-00		35- 20 -118B- 1 34	1
25530-01		35- 20 -118B- 1 -135	1
25531-01		35- 20 -118B- 1 143	1
25532-00		35- 20 -118B- 1 140	1
25533-00		35- 20 -118B- 1 141	1
25602-00		35- 20 -118B- 1 126	1
25603-00		35- 20 -118B- 1 101	1
25680-00		35- 20 -118B- 1 53	1
25682-01		35- 20 -118B- 1 19	1
25683-11		35- 20 -118B- 1 85	1
25685-00		35- 20 -118B- 1 93	1
25693-00		35- 20 -118B- 1 144	1
25694-00		35- 20 -118B- 1 131	1
25695-00		35- 30 -118B- 1 130	1
25698-00		35- 20 -118B- 1 72	1
25699-00		35- 20 -118B- 1 71	1
25711-00		35- 20 -118B- 1 109	1
25713-00		35- 20 -118B- 1 117	1
25715-00		35- 20 -118B- 1 154	1
25718-00		35- 20 -118B- 1 155	1
25719-00		35- 20 -118B- 1 125	1
25720-00		35- 20 -118B- 1 123	1
25722-00		35- 20 -118B- 1 158	1
25723-00		35- 20 -118B- 1 57	1
25724-01		35- 20 -118B- 1 156	1
25736-00		35- 20 -118B- 1 58	1
25737-00		35- 20 -118B- 1 2	1
25738-01		35- 20 -118B- 1 -122	1
25875-00		35- 20 -118B- 1 115	1
25879-00		35- 20 -118B- 1 152	1
25882-00		35- 20 -118B- 1 133	1
25883-00		35- 20 -118B- 1 142	1
25885-00		35- 20 -118B- 1 - 49A	1
25886-00		35- 20 -118B- 1 107	1

35-20-118B

SCOTT

22504
OVERHAUL MANUAL

PART NUMBER	AIRLINE PART NO.	CH-SECT-UNIT-FIG-ITEM	TTL REQ
26164-01		35- 20 -118B- 1 69	1
2837-01		35- 20 -118B- 1 80	1
2837-02		35- 20 -118B- 1 65	2
		35- 20 -118B- 1 113	
28965-00		35- 20 -118B- 1 90	AR
3-5 (COMP 77-545)		35- 20 -118B- 1 104	1
33359-213			19
		35- 20 -118B- 1 3	
		35- 20 -118B- 1 51	
		35- 20 -118B- 1 86	
33359-215		35- 20 -118B- 1 21	4
33359-228		35- 20 -118B- 1 30	2
34131		35- 20 -118B- 1 23	2
3501-02		35- 20 -118B- 1 60	1
55573-00		35- 20 -118B- 1 136	1
58526-00		35- 20 -118B- 1 61	2
6472-82		35- 20 -118B- 1 97	1
800325-00		35- 20 -118B- 1 119	1
800376-00		35- 20 -118B- 1 -149	1
800549-00		35- 20 -118B- 1 - 85B	1
800798-00		35- 20 -118B- 1 - 85A	1
800799-00		35- 20 -118B- 1 - 85C	1
802242-01		35- 20 -118B- 1 - 70	1
802954-01		35- 20 -118B- 1 - 50A	1
802955-01		35- 20 -118B- 1 - 29A	1
802956-01		35- 20 -118B- 1 - 2N	1
802957-01		35- 20 -118B- 1 20	1
8938-01		35- 20 -118B- 1 137	2
		35- 20 -118B- 1 139	
8938-04		35- 20 -118B- 1 106	1

35-20-118B